



T (450) 978-3403

1 (888) 528-8518

F (450) 978-2542

4656 Louis B. Mayer, Laval, QC H7P 6E4

www.durodesign.com

RE-VARNISHING A DURODESIGN BAMBOO FLOOR

RE-FINISHING A DURODESIGN FLOOR IS EASY

But first... You must read and understand these instructions completely before re-finishing a DuroDesign floor. In the event these instructions leave unanswered questions or if you would like additional information, please contact DuroDesign Customer Service at 1-888-528-8518 prior to beginning re-finishing.

REPAIR

Touch up nicks and scratches with supplied DuroDesign touch-up stain. Seal those areas with a quick-drying water-based poly-urethane spray (Varathane etc.) to prevent the stain from being washed away by the maintenance coat of varnish

PREPARE AND CLEAN

Sand the floor with a 12"x18" orbital flooring sander (SquarBuff, Alto) with 180 grit open-coat paper. Vacuum and tack the floor thoroughly with a damp cloth to remove all sanding dust

CATALYZE THE VARNISH

Stir gently while pouring the entire bottle of pre-measured catalyst into the MP765 varnish. Do not dump the catalyst in without stirring, as it may harden prematurely at the bottom of the can. Continue stirring for a couple of minutes to ensure catalyst is mixed in.

APPLY THE VARNISH

Pour the catalyzed varnish into a paint pan. Using the supplied synthetic pad applicator on an extension pole, apply the varnish in a smooth, even coat in one direction being careful not to miss any spots or leave puddles of varnish.

RE-APPLY THE VARNISH

Allow the floor to dry overnight. Apply a second coat of varnish the following morning.

ENJOY

Allow your floor to dry 24 hours before subjecting it to normal traffic. Wait a week before replacing area rugs to allow the urethane to fully cure.